

### Auszug von "Sv500m.hlp"

PC-AT compatible GPIB board and required driver need to be correctly installed in order to use the GPIB interface. See below. Usable GPIB board: National Instruments Corporations AT-GPIB or AT-GPIB/TNT Required driver: (To use with Windows 3.1 or use AT-GPIB board with Windows95)  $\mu$  v X ? L€í € È€ ff,ff,ff,ff,,ff,ff,ff,,f,f,ÿ ->[NI-488.2 Software for Windows and the AT-GPIB/TNT+,AT-GPIB/TNT(PnP), EISA-GPIB and AT-GPIB/TNT Version 2.7.1] (To use AT-GPIB/TNT with Windows95) ->[GPIB Software for Windows 95 Version 1.2] \*Consult National Instruments Corporation regarding the GPIB board and driver(specifications, price, installation and other information).

%€ ,ã Ò. € %€ ,      ãĐİøZ€ %€ , ãU T € %€ ,      ãI